


Hugiga_L66 MMS 設定




1.功能表 按 



2.設定 按確定 



3.網路設定 按選擇 



4.行動網路
按選擇 




5.存取點名稱 (APN)
按選擇 



6.CHT MMS
按選擇 




7.設定值(1)



8.設定值(2)



9.設定值(3)



10.設定值(4)

<http://mms.emoem.net:8002>




11.設定值(5)



12.設定值(6)



13.設定值(7)



14.設定值(8)



15.設定值(9)

